

CanaDream has a fleet of special winter units (Maxi Motorhome MHA) which are equipped with heated holding tanks, insulated water lines, double pane windows and generators.

If you are travelling in this unit during sub-zero weather, you will be able to utilize the water; however, you must take the following precautions:

1. **ALWAYS** leave your furnace on at a minimum of 16°C when not in the vehicle. The holding tanks are insulated, but also require the warm air from the furnace to keep them from freezing. Ensure the furnace is set to Auto and Heat at all times, except while driving.
2. **ALWAYS** ensure you have plenty of propane to keep your furnace running. Refill your propane tank before it gets to the ¼ tank level.
3. **ALWAYS** ensure you have plenty of fuel in the fuel tank. It is recommended that you always keep your fuel tank no less than 1/2 full. NOTE! The generator will not run if there is any less than ¼ tank of fuel present.
4. **ALWAYS** have the 'ARCTIC PAC' switch turned on. This switch supplies power to heating pads on the holding tanks and keeps the contents of the holding tanks from freezing. These heating pads have built-in thermostats and will only heat up when needed. The ARCTIC PAC will only work while plugged into external power at the campground, while the generator is running, or while the engine is running.
5. To enhance comfort, please keep the slide completely closed at night and when leaving the vehicle, when running the generator. This will reduce heat loss and, therefore, reduce how often the furnace turns on. The thermostat can be set to about 18°Celsius. Of course, this temperature can be adjusted to suit your personal comfort needs.
6. **ALWAYS** keep your blinds and privacy curtains closed at night to prevent heat loss.
7. **ALWAYS** keep your hot water heater on LPG, except while driving.
8. **DO NOT** connect to City Water.
9. **ALWAYS** keep the roof vent isolating cushions in. Open your roof vent a little to reduce any condensation issues. Roof vents must be closed when driving.
10. **ALWAYS** run the rear heater when the engine is running. When the engine is not running, plug in the electric heater provided, when connected to campsite power supply.